1 YEAR LIMITED WARRANTY

Green smoke®
it's electric™

GreenSmoke® Starter Kit User Guide

Thank You for Choosing Green Smoke®

Table of Contents:

What are Green Smoke® Electronic Cigarettes? 1
Green Smoke® Electronic Cigarette Benefits 2
Green Smoke® Starter Kit Contents 3
Getting Started 4
Charging the Battery 5
Using the USB Cigarette and Adapters 6
Product and Technology 7
Green Smoke® Flavors and Nicotine Levels 10
1 Year Limited Warranty 11
Troubleshooting 12
Cautions 13

Specifications:

model no. GSSK-002B

Specification	Input	Output
Home Adapter	100-240V	5.0V
Car Adapter	12-24V	5.0V
USB Charger	5.0V	4.7V
Specification	**Short Battery**	**Long Battery**
Puffs Per Charge	180-220	250-300
Charging Time	Up to 4 hours	Up to 5 hours
Length (Battery & Cartomizer)	4.6 inches (100 mm)	4.0 inches (116 mm)
Weight (Battery & Cartomizer)	0.5 oz. (14 g)	0.6 oz. (18 g)

The Green Smoke® electronic cigarette is a revolutionary new way to smoke.

Its flavored solution is vaporized into a smooth smoke-like vapor that provides you with an enjoyable smoking experience.

The Green Smoke® electronic cigarette was designed to give you a smooth and pleasurable smoking experience. The simple two-piece design, consisting of a long-lasting battery and a FlavorMax™ Cartomizer, produces a fresh, rich, smoke-like vapor without creating any offensive odors, ash, or cigarette butts. The Green Smoke® e-cig is unmatched in providing smooth airflow and vapor volume. E-cigarettes are not subject to many traditional cigarette smoking bans, allowing you to smoke your e-cigarette in many smoke-free zones.

GREEN SMOKE® ELECTRONIC CIGARETTE BENEFITS

The Green Smoke® electronic cigarette is an enjoyable alternative to traditional cigarettes. Some of the major benefits include:

- Ease of use and convenience
- Fresh, flavorful, smoke-like vapor
- No offensive odors
- Lighter on your wallet than traditional cigarettes
- Acceptable in many non-smoking areas
- Requires no flame and creates no ash
- No cigarette butts

GREEN SMOKE® STARTER KIT CONTENTS

Short Battery



Long Battery

USB Charger

10 Refill Cartomizers

USB E-Cigarette

Home Adapter

Car Adapter

GETTING STARTED

CONNECTING THE E-CIGARETTE BATTERY AND FLAVORMAX™ CARTOMIZER:
Remove a FlavorMax™ Cartomizer from its packaging and screw the battery into it. They should screw together easily when you line up the threads.

SMOKING THE GREEN SMOKE® E-CIGARETTE:
Inhale as you normally would when smoking a cigarette, allowing several seconds to pass between puffs. The LED at the tip of the battery will light up as you inhale.

REPLACING THE FLAVORMAX™ CARTOMIZER
You'll know that it's time to replace your FlavorMax™ Cartomizer when you notice a significant reduction in vapor volume while smoking. To replace the FlavorMax™ Cartomizer, simply unscrew the used cartomizer from the battery and screw on a fresh one. Please visit www.greensmoke.com to view the full line of FlavorMax™ Cartomizers.

Tip: To ensure the freshest smoking experience, leave the FlavorMax™ Cartomizer in its packaging until use.

CHARGING THE BATTERY

There are 2 ways of knowing that it's time to recharge your e-cig battery. 1) When there is a noticeable reduction in vapor volume and 2) when the LED at the tip of the battery flashes three times. *Note: If you are using a fully charged battery, reduction in vapor volume might also indicate that the cartomizer needs to be replaced.*

To continue enjoying your Green Smoke® electronic cigarette while your batteries are charging, use the included USB e-cigarette. **The USB e-cigarette does not require charging.**

TO CHARGE YOUR BATTERY:

- Unscrew the cartomizer from the e-cigarette battery.
- Screw the e-cigarette battery into the Green Smoke® USB charger.
- Plug the USB charger into a USB port on your computer or into a USB home or car adapter.
- When plugged in, the light on the charger will turn red, indicating that the battery is charging.
- It takes 3-5 hours to fully charge a battery. When the battery is charged, the light on the USB charger will turn from red to green.

USING THE USB CIGARETTE AND ADAPTERS

USING THE USB CIGARETTE

Included in the starter kit is a Green Smoke® USB e-cigarette. You can use it while your other batteries are charging, or whenever you are near a power source. The USB e-cigarette can be plugged into the USB port of your computer or into the included wall or car adapter. To use the USB e-cigarette, simply screw on a FlavorMax™ Cartomizer and plug the USB cable into the USB port on your computer or one of the adapters. You may then smoke your USB e-cigarette normally. *Note: The computer must be turned on to power the USB e-cigarette*.

USING THE WALL AND CAR ADAPTERS

Your starter kit comes with two high-powered adapters, a wall adapter and a car adapter. These adapters will allow you to charge your rechargeable e-cigarette batteries in any standard wall or car outlet. Simply screw the battery into the USB charger, plug the charger into the adapter and plug the adapter into an outlet. These adapters will also work directly with the USB e-cigarette. To enjoy your USB e-cigarette in your home or in a car, simply plug the USB e-cigarette into the USB port of the adapter and plug the adapter into a wall outlet or your car's power outlet.

Warning: *Do not use this product while driving. If you do, you significantly increase the risk of an accident.*

The Green Smoke® electronic cigarette gives you an unmatched smoking experience. It features a two-piece design consisting of a rechargeable lithium-ion battery and our FlavorMax™ Cartomizer which contains a built-in heating element called an atomizer. Included in the starter kit is a USB e-cigarette that will give you a constant source of power and can be used when your other batteries are charging. Manufactured to the highest standards, each Green Smoke® electronic cigarette is visually and mechanically tested to ensure quality and functionality.

To protect our environment, please mail us your used batteries and we will gladly recycle them for you. You can also find the battery drop-off location nearest you by going to: www.call2recycle.org

THE FLAVORMAX™ CARTOMIZER - FRESH AND EASY TO USE

The Green Smoke® FlavorMax™ Cartomizer produces a thick smoke-like vapor and has been re-engineered to make inhaling even easier. Each FlavorMax™ Cartomizer produces vapor volume comparable to the smoke volume of up to 1.5 packs of regular cigarettes – approximately 360 puffs. All Green Smoke® FlavorMax™ Cartomizers are triple sealed, which ensures that you are getting the freshest cartomizer possible.

Green Smoke® was a pioneer of the cartridge design that combined the cartridge with the atomizer (cartomizer). This cartomizer design, which is now the industry standard, offers a much more pleasant e-smoking experience. When a Green Smoke® cartomizer runs out of solution, the entire cartomizer, along with the built-in atomizer, is replaced with a brand new one. This design prevents the atomizer from clogging, and avoids reduced performance of the e-cigarette.

When the time comes to replace the cartomizer, all you have to do is screw off the used cartomizer and screw on a new one. The convenient two-step cartomizer replacement is simple and makes the Green Smoke® electronic cigarettes easy to use.

THE BATTERY – RELIABLE AND LONG LASTING

The Green Smoke® Starter Kit comes with one long rechargeable battery, one short rechargeable battery and one USB e-cigarette.

The Green Smoke® e-cigarette battery is engineered to provide excellent air flow, simulating a true smoking experience. The high quality lithium-ion cell in the rechargeable batteries ensures a long life and an even, consistent smoking experience.

The short rechargeable battery is designed to make your e-cigarette more lightweight and easy to carry. The long rechargeable battery is designed to give you more power so you can enjoy your cigarette for longer between charges.

The USB e-cigarette plugs into any standard USB port and can be used with your computer, or the included wall of car adapter. It ensures that you always have constant power for your electronic cigarette, even when your other batteries are charging.

NICOTINE LEVELS & FLAVORS

Green Smoke® electronic cigarettes come in a range of rich, refreshing, full-bodied flavors designed to provide you with the best smoking experience possible.

Absolute Tobacco™ • Tobacco Red Label™ • Tobacco Gold™ • Menthol Ice™
Vanilla Dreams™ • Mocha Mist™ • Smooth Chocolate™

The Green Smoke® cartomizer contains 4 main ingredients: Propylene Glycol, Vegetable Glycerin, Artificial Flavoring, and Nicotine. There are many new flavors currently in development. Check our website www.greensmoke.com for the latest updates. *Note: Mocha Mist, Vanilla Dreams, & Smooth Chocolate are not available for sale in California, Oregon, & Nevada.*

NICOTINE LEVELS

The following nicotine levels are available (by volume): **Zero** (0%)* , **Ultra Light** (0.6%), **Light** (1.2%), **Full** (1.8%), **Strong** (2.4%)

** May contain traces of nicotine.*

ONE YEAR LIMITED WARRANTY

Green Smoke®, Inc., only guarantees Green Smoke® products purchased from an authorized reseller or distributor. Such products are guaranteed to be free from defects in their component materials and workmanship with normal use for one (1) year after date of purchase. This warranty does not cover any defects or costs caused by:

- Modification, alteration, repair, or service of this product by any person or company other than Green Smoke®, Inc.;
- Physical abuse to, or misuse of, the product or operation thereof in a manner inconsistent with the use indicated in the instructions;
- Any use of the product other than that for which it was intended; or
- Shipment of the product to Green Smoke®, Inc., for service.

Any express warranty not provided herein, and any remedy that might arise by the inference or operation of law other than that of the warranty contained therein, is hereby excluded and disclaimed, including the implied warranties of merchantability and of the products' fitness for a particular purpose. Replacement or repair of product is your exclusive remedy under this warranty. For product support, please call customer service at 1-888–427–9258, or email us at service@greensmoke.com.

TROUBLESHOOTING

ISSUE	SOLUTION
The light on the battery blinks when you inhale.	The battery charge is low. Unscrew the cartomizer and screw the battery into your USB charger to recharge.
The e-cigarette produces little or no vapor.	Take a few strong, short puffs to heat the atomizer. If that doesn't work your cartomizer needs to be replaced.
The cigarette is producing a burnt smell.	This is normal and just means that the liquid in the cartomizer is used up; you need to replace your cartomizer.
The flavor has a burnt taste.	This is normal, and means that the liquid in the cartomizer has been used up and the cartomizer needs to be replaced.

CAUTIONS

- Keep the batteries and cartomizers in a cool, dry place, away from direct sunlight.
- Keep the batteries away from high temperatures when storing and charging.
- Protect your electronic cigarette from impact.
- Do not use with accessories not manufactured by Green Smoke®, Inc.
- Do not expose your electronic cigarette to water or moisture.
- Do not charge or smoke the e-cigarette outside the temperature range of 39°F - 104°F (4°C - 40°C).
- Do not break open the cartomizer.
- Avoid direct contact of cartomizer's liquid concentrate with skin.
- Please abide by relevant local smoking laws.

THANK YOU FOR CHOOSING GREEN SMOKE® ELECTRONIC CIGARETTES.

Green smoke®
it's electric™

www.greensmoke.com

#GSSK - 002B

Distributed by Green Smoke , Inc. USA | Printed in China

WARNING:

This product is intended for use by persons 18 or older, and not for children, women who are pregnant or breast feeding, or persons with or at risk of heart disease, high blood pressure, diabetes or taking medication for depression of asthma. If you have a demonstrated allergy or sensitivity to nicotine or any combination of inhalants, consult your physician before using this product. This product is sold purely for recreational purposes – it is not a smoking cessation product and has not been tested as such. You must be over the legal age in your state to buy or use this product. Nicotine is highly addictive and habit forming. Keep out of reach of children.This product contains nicotine, a chemical known to the state of California to cause birth defects or other reproductive harm. Cartomizers labeled with 0% nicotine are manufactured in the same factory that also manufactures nicotine cartomizers and may contain traces of nicotine.